

Waste Pickup Summary

When do I request a pickup?

When your waste container is full, **OR**

When your waste containers have been in your SAA, RWCA, or MWSAA for 9 months, **OR**

When you no longer need the waste container, **OR**

When you are leaving the Laboratory (Please request a pickup at least 2 weeks prior to your final day).



How do I request a pickup?

Hazardous Waste

1. Seal the container. No waste should be added after you've decided to request a pickup.



2. Fill out an electronic Hazardous Waste Disposal Requisition. Most information needed to fill out the requisition can be found on the "Hazardous Waste" label on the container. Sign and date the form. For more details, see Section 1.4 of the Generator Guides.

3. If your hazardous waste is from a Radioactive Materials Area (RMA) and is not contaminated with radioactivity, complete and sign the "RMA Waste Certification Form". (If you're not sure whether the waste is contaminated, please contact your Health Physics Radiation Control Technician.)
4. Fax the completed RMA Certification (if appropriate) and associated accumulation logs, or other supporting information (MSDS, analytical results) to **x4838**.

Radioactive/Mixed Waste

1. Seal the container. No waste should be added after you've decided to request a pickup.
2. Finish filling out the Radioactive Material Tag (Sections A, F, G should already be completed). For more details, see Section 2.1 of the Generator Guides
3. Complete the Radioactive/Mixed Waste Requisition
4. Fax the completed Radioactive Material Tag, Radioactive/Mixed Waste Requisition, accumulation logs, and any other supporting information to **x4838**.

If you have provided complete information, your waste will be picked up within about 7 days. If information is missing or specific information is needed, we will call you.